

BACKOUTS PREVENTERS

ARTICULATE BACKOUT PREVENTER

The backout preventers increase operator safety by preventing the tool from backing out of the pipe.
Pantograph moving mechanism for fast nozzle into the pipe to be cleaned.



Simply open the compartment and rotate the collet to the proper hose size and re-insert.



SIMPLE BACKOUT PREVENTER

The contoured handle is designed to make it easy to hold.
It quickly adapts to different sizes of hoses.
It includes three adapters for hoses DN4, DN5 and DN6.



PIPE NOZZLES BACKOUT PREVENTERS

These devices are specifically designed to enhance operator safety. Prevent the nozzle exit of the pipe.
Several options are available including fixtures for small diameter pipes, pipes with various flange bolt circle diameters, and adapters for pipes with no-flange entry.



BJ 305	Application pipes	Hose range
	Ø50 - Ø150 mm	De 4 mm a 3/8"

BJ 310	Application pipes	Hose range
	Ø100 - Ø200 mm	De 3/8" a 3/4"

Includes clamp for securing the device to the tube



BJ 320	Application pipes	Hose range
	Ø125 - Ø430 mm	De 3/8" a 3/4"

BJ 325 BJ 340*	Application pipes	Hose range
	Ø380 - Ø914 mm	De 3/8" a 3/4"

**No-Flange Kit*